


CAPITAL
DISTRIBUTION LLC.



**CD-1S-1200
SIMPLEX 2"
THERMOSTATIC MIXING VALVE STATION**

Complies with 1/4/14 Federal Low Lead Laws



Capital Distribution LLC

CD-1S-1200 SIMPLEX THERMOSTATIC MIXING VALVE

Capital Distribution mixing valve stations are designed to serve the convenience of the facility maintenance staff to facilitate installation, maintenance and repair. The thermostatic hot water mixing valve provides a cost effective solution for high or low volume requirements.

Features and Benefits:

- Single moving part in a lead free body
- Large waterways which eliminates issues such as gumming
- Easily replaceable inexpensive cartridge
- All mixing valves have ball valve shut off
- Temperature gauge
- Local drain simplifies setting temperature
- Custom Designs

Included: Approvals:

Mixing Valve: NSF / ANSI 372

Ball Valves: CUPC / NSF

Check Valves: CE / UL / NSF

Temperature Gauges: CSA Verified

Boiler Drain: CSA / IAPMO

Technical Specifications:

- Model: CD-1S-1200 Simplex
- Inlet / Outlet: 2 Inch
- Dimensions: 22" W x 24" H x 16" D
- Will supply mixed water between 100° F and 140° F.
- Hot water inlet temperature at least 20° F higher than the outlet temperature.
- The maximum working pressure shall be 125 PSI.
- Simplex, Duplex and Triplex shall meet ASSE 1017.
- Maximum pressure differential between the incoming cold and hot water shall be less than 30 PSI. Circulator and Aquastat requirements begin at 100 feet developed length. Consult factory for water systems without circulators.

All parts shown are included in the system. Actual system design may vary. Some assembly required.



Repair kit cartridge
easy to replace and
install



Recirculation Line

Complies with 1/4/14 Federal Low Lead Laws

Warrantees are passed through and as published in the original equipment manufacturer's literature that is included with this system. In no event shall the manufacturer be liable for incidental or consequential damages or limitation on how long a warranty lasts. It being intended that purchaser's exclusive remedy is limited to replacement of defective products. Water damage exclusion: It is understood that the manufacturer accepts no responsibility for water damage regardless of what or who caused water damage or any consequential personal injuries, liabilities or property damages resulting.


172 Broadway Suite 205 H Woodcliff Lake, NJ 07677

Tel: 201-690-6512 Fax: 908-737-1373

www.tristateboosters.com tristateboosters@yahoo.com



CD THERMOSTATIC MIXING VALVE PERFORMANCE CURVE



2" Mixing Valve Head Loss

Pressure drop (PSI)	5	10	15	20
Volume (GPM)	60	80	97	110




Capital Distribution Thermostatic Mixing Valves feature only one moving part & wide open waterways which **IMPROVES PERFORMANCE & SIMPLIFIES MAINTENANCE**

Remove the mixing valve cap and insert the replacement cartridge

IT'S EASY !!

1" Repair



1 1/4" & 2"



Complies with 1/4/14 Federal Low Lead Laws

Note: Check "Mixing valve Technical specifications & Installation instructions" for procedure for changing mixing valve cartridge.




CD THERMOSTATIC MIXING VALVE FEATURES, BENEFITS & REQUIREMENTS

Features and Benefits:

The single system SIMPLICITY mixer provides a cost effective thermostatic hot water mixing valve for the systems with either high or low volume requirements.

- A single moving part in a bronze body with large waterways eliminates the issues faced with an old fashioned high/low mixer styles. The bronze body eliminates the buildup of rust and scale, keeping the valve clean, thus reducing failure. Eliminates tight tolerances, multiple moving parts and gumming, sticking associated with old fashioned hot water mixing valves.
- Replaceable cartridge for the mixer dramatically reduces repair costs.
- All mixing valves have "Ball valve shut-offs" as a standard feature, allowing independent temperature adjustment by isolating single and multi-unit stations.
- System is complete with check valves, ball valves, thermometer, local drain and recirculation line to facilitate easy installation.
- Valve is designed to operate between water velocities of 7.5 to 10 feet per second.
- Mixing begins between 1 – 2 GPM.

The diagram below illustrates the simplicity and ease of replacing a cartridge style thermostat



Requirements:

The SIMPLICITY temperature actuated mixing valve is approved to control water temperature in domestic potable hot water systems from the hot water source.

- The system will supply hot water between 100 °F and 140 °F.
- The temperature of the supplied hot water should be at least 20 °F higher than the expected outlet temperature.
- The maximum working pressure in the system should not exceed 125 PSI.
- The system shall meet ASSE 1017
- The maximum pressure differential between the incoming cold and hot water should not exceed 30 PSI.
- Circulators and Aquastat requirements begin at 100 feet developed length. Consult factory for water systems without circulators.

VALVE BODY:	Cast Bronze	SHUTTLE:	Noryl	O-RINGS:	Buna-N
THERMAL	Bronze/	RETURN	Stainless steel	OVERTRAVEL	Stainless steel
ELEMENT:	Stainless steel	SRPING:		SRPING:	
RETAINER:	Brass (3/4" - 1")				
	Cast Bronze (1 1/4" - 2")				

172 Broadway Suite 205 H Woodcliff Lake, NJ 07677

Tel: 201-690-6512 Fax: 908-737-1373


www.tristateboosters.com tristateboosters@yahoo.com



PROBLEM/CAUSE

ANSWER

1] Fluctuating or erratic hot water temperature <ul style="list-style-type: none">• Large demand for hot water• Unbalanced pressures	<p>Large demands for hot water will cause the mixing valve to operate incorrectly. This valve is not designed to compensate for flow rates exceeding specifications. When hot water is removed faster than the heating source can reheat the water, the temperature will drop below the valve set temperature.</p> <p>If the pressure differential between the hot and cold water inlet lines is greater than 30 PSI, a balancing or throttling valve may be needed on the cold water line to make up for the heat loss in the heating source.</p>
2] Hot water backing up in cold water line <ul style="list-style-type: none">• City water pressure drops causing hot water pressure to override cold water pressure	<p>Install a check valve in the cold water line</p>
3] Water temperature does not adjust to the desired temperature <ul style="list-style-type: none">• Unbalanced pressures• Heating source inadequate	<p>If the pressure differential between the hot and cold water inlet is greater than 30 PSI, a balancing or throttling valve may be needed on the cold water line to make up for the heat loss in the heating source.</p> <p>The heating source may not produce enough hot water to maintain the desired temperature.</p>
4] Failure of Thermostat <ul style="list-style-type: none">• Thermostat exposed to extreme high temperature• Build up of mineral deposits due to corrosive water conditions• Electrolysis	<p>Thermostat on heating source may be set too high causing water temperatures to exceed 210°F. Turn thermostat on heater down. The mixing valve must be located at least 8" to 12" below the hot water source.</p> <p>Cleaning the thermostat frequently and removing deposits will help prolong life of thermostat</p> <p>Electrically ground the piping system or install dielectric unions</p>



Temperature adjustment:

To adjust temperature, simply turn the bolt [remove the yellow knob] to the desired setting. Turn the bolt clockwise for lower temperatures or counterclockwise for higher temperatures. The water should be flowing while adjusting the valve to allow the thermostat to adjust. Use a thermometer or temperature gauge downstream of the valve to check the water temperature.

Legend

	Hot Water
	Cold Water
	Tempered Water
	Check Valve
	Ball Valve